



# Brewing / Cleaning Guide

LCC Classic Select Roast Shelf Stable Liquid Coffee



Foodservice

Enjoy all the rich flavor you've been looking for from a liquid coffee with the added convenience and flexibility of on-demand equipment. The following step by step guide will ensure your success with the operation and maintenance of your Classic Select Roast shelf stable liquid coffee program.

## Filling The Machine



1. Insert box into cooler with box spout cut out and instructions facing the front of the machine. Follow packaging directions:
  - 1) Remove Circle A and lift flap B (do not tear off)
  - 2) Slide bag spout into circular hole
  - 3) Lock bag spout in place with flap B



2. Remove the foil label from the spout and 1) insert **Quick-Clic** into spout until 2) it clicks with the bag spout.



3. With a cup in position, set the toggle switches to **Run** and **Prime** positions. Press the regular coffee selection until the liquid fills the tube and then begins to fill the cup. Do the same for the decaf selection. After priming, set the toggle to normal. It is now ready for brewing.



Release Lever

4. When changing the Bag-in-Box, press the release lever on the **Quick-Clic**. Carefully remove and wipe clean. Remove the empty Bag-in-Box and replace with new Classic Select Roast product.

### Door Instruction



Note: If pump tubing needs to be replaced call Kraft service at 1-800-7-MAXWEL. The replacement instructions are on the interior of door.

## Brewing Guide



1. **When filling a cup**, position under the nozzle, press and hold coffee or decaf selection until the cup is 2/3 full and release the selection. If needed, the stop button can be pressed to keep the cup from overflowing.



2. **When filling a glass bowl (carafe)**, place in position under spout. First press the carafe selection, then press the coffee or decaf to fill the carafe. The selection can be preset to automatically stop at 60 ounces. If needed, the stop button can be pressed to keep the carafe from over filling.





# Brewing / Cleaning Guide

LCC Classic Select Roast Shelf Stable Liquid Coffee




Foodservice


## Cleaning Unit



1. Open unit door. Remove **Quick-Clic** from spout, wipe clean and place in a container of clean hot water.



2. Set the toggle switches to the **Rinse** and **Run** position. Press the appropriate coffee or decaf selection that the container is in and dispense until the liquid becomes clear.



3. Remove and wash the air filter, drip tray and drip tray cover in a mild detergent. Rinse and dry the items thoroughly.



4. With a clean damp cloth, wipe down both the inside and outside of the machine door, including the nozzle and back splash.

**NOTE: Follow Weekly Sanitizing Guide Instructions On Inside Of Door**

**For Service Call Kraft: 1-800-7-MAXWEL**