



# Brewing / Cleaning Guide



**Foodservice**

Enjoy all the rich flavor you've been looking for from a liquid coffee with the added convenience and flexibility of on-demand equipment. The following step by step guide will ensure your success with the operation and maintenance of your Maxwell House® frozen liquid coffee program.

## Filling The Machine

All instructions will be shown from the Powerplex D4 machine unless a significant difference on the D5 machine exists and thus the difference will be noted.



1. Pull back tab on liquid coffee canister, but do not remove it completely. Insert suction tube in liquid canisters and twist into place.



2. Be sure to place regular coffee on left side and middle of interior cavity and decaf on right. With the canister in place, operate the relevant PRIME switch until concentrate comes out of the outlet nozzle on the front of the dispenser. Then operate the FLUSH switch briefly to remove any pure concentrate from inside the nozzle.



D5 - Two canister storage only. (Regular - left, Decaf - right)



3. When changing the canister, remove canister from suction tube and wipe straw clean. Insert new canister and throw empty canister in recycle bin.

## Brewing Guide



1. Place cup under spout on support tray and press button corresponding to size of cup and type of coffee you want dispensed. Coffee will stop flowing once preset portion is dispensed, but if for some reason it doesn't push **Stop** button.



D5 - Place cup under spout and pull lever forward and hold until cup is 2/3 full.



2. If your cup size is larger than 16oz. you will need to lift up cup tray as shown above and place cup directly on drip tray and follow procedures from Step #1.



3. Dispense hot water by pushing the hot water button until cup is full. Note: If the power is shut off temporarily and locks the machine, simply turn off the machine power switch for 30 seconds and turn it back on - if the problem does not correct itself, call for service.



D5 - Pull **Hot Water** lever for hot water.



# Brewing / Cleaning Guide




Foodservice

## Cleaning Unit

A=Left Suction Tube  
C=Middle Suction Tube  
B=Right Suction Tube



1. Open unit door. Remove suction tube from coffee canister. Wipe clean and insert tube into a container of hot water (approx. 8oz).



2. Operate corresponding **Prime** switch for tube location until coffee is displaced with water.



D5 - A is Left Suction Tube  
B is Right Suction Tube



3. When cleaning of coffee line is complete replace canister and hold the **Prime** switch until coffee flows out the nozzle. (Repeat for all positions within compartment)



4. Remove dispenser nozzle and clean daily. The dispenser nozzle can be cleaned throughout the day using the FLUSH switch.



Drip Tray Cover

Cup Tray

Drip Tray



5. Remove and wash the drip tray, drip tray cover, and cup tray in a mild detergent solution. Rinse thoroughly.

**NOTE: Following Weekly Sanitizing Guide Instructions On Inside Of Door**

For Service Call Kraft: 1-800-7-MAXWEL